

▼▼▼▼▼ BULMAN PRODUCTS, INC.

1650 MCREYNOLDS NW. GRAND RAPIDS, MICHIGAN 49504
PHONE (616) 363-4416 FAX (616) 363-0380
www.bulmanproducts.com

ASSEMBLY INSTRUCTIONS FOR M780 RIBBON DISPENSER

1. TO INSTALL RIBBON HOLDERS, LOOSEN PLASTIC SET SCREWS AND SLIDE HOLDERS ONTO DISPENSER AS SHOWN BELOW. ONE WILL BE LOCATED AT EACH END OF THE TROUGH SECTION OF DISPENSER.
2. INSTALL RUBBER GROMMETS AS SHOWN BELOW.
3. LOAD RIBBON ROLLS INTO TROUGH BETWEEN HOLDERS. THEN ADJUST RIBBON HOLDERS UNTIL ROLLS ARE SECURE AND TIGHTEN SET SCREWS.
4. FEED RIBBON ENDS UNDER SPRING ON DISPENSER. RIBBON DISPENSER M780 IS NOW READY TO OPERATE.

